

ANSCO

BINGHAMTON, N. Y. MADE IN U. S. A.

PD16
JN151

How to use your

PIONEER

T. M. REG. U. S. PAT. OFF.


CAMERA

ANSCO PIONEER CAMERA

1. SHUTTER RELEASE

2. OPTICAL VIEW FINDER

3. WINDING KNOB



The Ansco Pioneer Camera is a modern, compact camera especially designed to enable you to take good pictures with the minimum of effort. Outdoor snapshots can be made with box camera simplicity and the inexpensive Flash Unit, which is sold separately, quickly converts the camera into a synchronized flash camera, making indoor photography as easy as outdoor snapshots.

Although you can secure excellent results with your Pioneer Camera without possessing a great deal of photographic knowledge, we advise you to read the following instructions carefully. For more complete details on picture-taking, read "Better Photography Made Easy," a particularly helpful 60-page book, published by Ansco and sold by most photographic dealers at \$.25 per copy. Ansco also maintains a special department to answer your inquiries and furnish expert advice on your photographic problems.

The PD16 Pioneer Camera takes 8 pictures $2\frac{1}{2} \times 4\frac{1}{4}$ inches on 616 (PD16) roll film. A wide variety of Ansco roll films is available in this size. Plenachrome film is recommended for all-around daytime use under average conditions. For pictures early in the morning or late in the afternoon or on dull days, use Supreme. Superpan Press has exceptional speed and is particularly recommended when the light is extremely unfavorable. All of the above mentioned films may be used when taking flash exposures.


LOADING

Your Pioneer camera may be loaded or unloaded in daylight; however, these operations should be done in subdued light; never in direct sunlight.

Open the back of the camera by lifting the catch on the side just below the winding knob. Pull out the winding knob and remove the cone from the inside of the camera. As you remove the cone, note its position so that when it is returned to the camera with a new film it will be in the correct position.

Place the fresh roll of film so that the holes in the ends of the spool engage the pins on the arms A and B, Fig. 2. Break the seal and draw the


FIGURE 2



paper over the metal rollers (never attempt to thread the paper under these rollers) and across the wide mouth of the cone (Fig. 3). Be very certain that the red or green side of the paper is out, the black side facing the inside of the cone. Now thread the pointed end of the paper into the longer slot of the takeup spool. With the winding knob pulled out so that it will not interfere, place the cone back in the camera. The side bearing the wording "Top" should be up. Press in the winding knob and give it a few turns sufficient to bind the paper and assure its firm grasp by the takeup spool.

Close the back of the camera and turn the winding knob until the figure "1" appears in the red

FIGURE 3






FIGURE 4

window on the back of the camera (Fig. 4). An indicating hand and a row of dots will be seen shortly before this first figure appears in place. The camera is now ready for the first exposure.

Immediately after taking the first picture, wind again until figure "2" appears in the red window, and so on until the roll has been completely exposed. After the eighth, and last, exposure, continue to turn the winding knob until the red or green paper is completely wound off onto the takeup spool.

TAKING SNAPSHOTS

To make a snapshot exposure, hold the camera

to your eye (Fig. 5), compose the subject in the view finder, and press down on the red shutter release. A single downward stroke of the shutter release operates the shutter, opening and closing it. To avoid moving the camera, hold it firmly, use a slow, steady pressure rather than a quick, jerky motion when operating the shutter.

FIGURE 5



Fig. 5 shows the correct position of the camera for horizontal pictures. For vertical pictures, turn the camera to a position that is at right angles to the one shown.

The addition of an Ansco Light-Yellow Filter (size No. 29) which can be purchased from your local dealer, will greatly improve your pictures when the light is extremely bright. This filter slips on over the lens mount and will be found useful when photographing landscapes, sunny beach scenes, bright snow scenes, and cloud effects.

FOCUSING

The Pioneer Camera is a fixed-focus camera which photographs everything from 8 feet to infinity. In order to take close-ups, a portrait attachment is necessary. With this accessory, you will be able to take head and shoulder portraits at a distance of $3\frac{1}{2}$ feet from the subject. An Ansco Portrait Attachment No. 29 is the correct size for this camera and may be purchased from your local dealer.

UNLOADING

When the last exposure has been made, completely wind the film onto the takeup spool, open

the back of the camera, pull out the winding knob and remove the cone from the camera.

Fold under the pointed end of the red or green paper and seal the spool with the "exposed" sticker. The film is now ready to be developed and printed.

To prepare the camera for the next roll of film, move the empty spool to the takeup position.

TO MAKE FLASH EXPOSURES

To make synchronized flash exposures with your Pioneer Camera, you must first purchase an Ansco Flash Unit, two fresh, penlight-size batteries and a few small or medium-size photographic flash lamps. Consult the exposure table for the types of lamps which are recommended for the various Ansco films. The Flash Unit may be purchased from your local dealer.

When taking flash pictures, always operate shutter several times before loading the camera with film. This assures clean contact points and smoother operation of shutter.

IMPORTANT — Make sure that the batteries are fresh. Fresh batteries will last for about one hundred exposures but lose their strength with age, three months being the average life of a battery when used for flash work. Worn out bat-




FIGURE 6

teries will either not flash the lamp at all, or will flash the lamp too late for proper synchronization.

Remove the metal back of the flash attachment by lifting up on one of the side clamps. The batteries fit inside the attachment, as shown in Fig. 6. Make sure that the top and bottom of batteries and all contact points in battery box are clean and that the batteries are in series, or, in other words, one should be tip up and one tip down, as marked inside the battery box.

Replace the metal back and attach the flash unit

to the camera (Fig. 7) by plugging it into the holes in top of camera. Spread the notch slightly in each prong to assure snug fit.

When you are ready to make a flash exposure, screw a flash lamp into the socket of the Flash Unit. Simply press down on the shutter release as you would for an ordinary snapshot. The shutter and lamp are synchronized so that the lamp flashes during the brief time that the shutter is open.

FIGURE 7



Light varies with the distance from the subject, and with the different type lamps. Consult the exposure guide for exposure detail.

Due to the small bayonet-type base on the Photoflash No. 5 and the Superflash Press 25, an adapter is needed when using these lamps, and is available through your dealer.

FIGURE 8



EXPOSURE TABLE

Film	Distance from Camera to Subject	
	Small Size * Lamp	Medium Size ** Lamp
Superpan Press	12 to 15 ft.	15 to 25 ft.
Supreme	8 to 12 ft.	12 to 15 ft.
Plenachrome	6 to 9 ft.	9 to 12 ft.

* Superflash No. 0, Press 25, Press 40, Photoflash No. 5 or No. 6.

** Superflash No. 2, Press 50, Photoflash No. 22 or No. 31.



USE ANSCO 616 (PD16) FILM

FOR BEST RESULTS FOLLOW THESE SIMPLE RULES

1. Never use force if parts seem to jam. Proceed carefully and find cause for obstruction.
2. Do not load and unload in direct sunlight.
3. Attach paper leader of new film to takeup spool firmly and evenly. Fasten back of camera securely.
4. Keep the lens and inside of camera clean and free from dust. To clean lens, use cleansing tissue or a soft linen or cotton cloth.
5. Wind film immediately after taking each picture.
6. Do not let sun shine on lens.
7. Hold camera level and press the shutter release without moving the camera. The slightest movement may cause a blur.
8. Don't try to get too much in one picture. Take time to compose the subject in the finder and select your backgrounds carefully.
9. Have film developed soon after it is exposed.
10. Wherever you go, take your camera along. Remember that there are wonderful pictures to be had at all times around the home. The snapshot of today is the treasure of tomorrow.
11. When using the flash attachment, do not screw the flash lamp into the socket until just before making the exposure. This will minimize the chances of the lamp flashing accidentally.
12. Use Ansco film and always keep a roll on hand. Don't be caught unprepared when the opportunity arises for a good picture.