

commonly known as the 12V battery. Replace the battery, the release of the screw on the panel, you can replace the battery.

6, Q: Mobile phones, walkie-talkie to detect whether an impact?

A: There are Mobile phones and walkie-talkie frequency is in the "ghost detector" to detect the frequency of people, there is around mobile phones, walkie-talkie in the call, "Please suspend the probe. However, mobile phones, walkie-talkie in a boot but not when the call does not affect "the specter of the use of detectors.

7, Q: Is the indicator light flashes, the sound will definitely ring a "pinhole camera" or "micro-listening device"?

A: No.

Flashing lights, sound ringing around is to prove that emissions of suspicious objects, please continue to search, to determine the location of suspicious objects in the identification of suspicious objects emissions is. For example, the law of the phone will be launched, so the indicator light flashes detectors, that detect the sound of ringing cell phone signals.

8, Q: Why are my "ghost detector" In some places the old flashing lights, sound is always ringing?

A: There are suspicious that the local wave, a gradual reduction of the antenna, please continue to search to determine the location of suspicious objects. When shortened antennas, anywhere in the room, light does not flicker, the sound is not ringing, the radio that the suspect

from a distance. 9, why in some room near the window on the flashing lights, sound on the ring?

A: There are emissions in the window object, such as the use of mobile phones was on the outside.

10, Q: My "ghost detector" light is always light, sound does nothing?

A: Please try changing the battery, such as not enough, please contact the Department with high-tech services.

11, Asked: "ghost detector" can detect the radar?

A: If it is in the "ghost detector" work the work of the frequency range of radar, can be detected.

12, Asked: "ghost detector" product quality?

A: The "ghost detector" chip technology using SMT production, all components undergo strict testing to ensure that the user's ease of use.

Tips

1, The product is a radio wave detection device, it is bugging you to detect wireless furtive means of an auxiliary equipment; and can not be used as the basis of confirmation of the judge.

2, When the radio suspicious when professional advice should be.

Ghost Detector


Manual User

High-tech research

Introduction

Explorer ghost detector used to detect R F radio frequency wireless broadband designed to test Adventure 1--10M firing frequency range of 100-2600MHz between the wireless transceiver equipment (such as wireless pinhole video cameras and wireless tapping devices, ect.). Can effectively prevent in all cases were tapping with the videotaping, for example:

1. Business negotiations, when the confidentiality of the contract;
2. To check hotels, guest houses, public toilets, swimming pools, changing rooms, whether there is a wireless pinhole camera;
3. Places of entertainment or to prevent the videotaping when dating men and women;
4. Military facilities or government agencies of confidentiality;
5. Companies, factories, cinemas or art galleries to prevent the videotaping; what people in places (eg home) to protect personal privacy.



Use Detection, follow these steps:

- 1, First pulling up the antenna.
- 2, Keep pressing the "A" button at the same time bright light when moving about when receiving radio waves, the sound ringing indicator light flashes at the same time can be long-range (depending on the strength of transmission power) to launch the region lock.
- 3, Continued to press the "B" key to search for short-range missiles, when the received radio waves, the sound ringing indicator light flashes at the same time.
4. When sustained by the "B" key to search for short-distance, if the distance from ultra-2M may be a result of the launch power of large objects, or interference with, at this time may be appropriate to shorten the antenna Battery replacement: Use 12V car battery remote control, open the panel to replace the screw.

Frequently Asked Questions

1. Asked: "ghost detector" on human health and whether it will affect other electrical equipment?

A: No impact.

"Ghost detector" is a passive detection equipment, it does not launch any electromagnetic wave, so it will not interfere with any electrical equipment, it will not affect human health.

2, Asked: "ghost detector" is the number of the

frequency range?

A: The "ghost detector" is the detection frequency range: 100-900MHz, 1100. 1200/1300/2400MHz, Wireless to launch the "pinhole camera" to use the frequency: 900/1100/1200/1300/2400MHz Wireless "micro-listening device," the use of the frequency: 100-800MHz

3, Asked: "ghost detector" to detect how much distance?

A: The general is a 1-10M, mainly depending on the measured objects and the environment may be different.

4, Q: How to confirm the location of suspicious objects?

A: At the beginning of detection, please antenna all open sloshing around find their voices ringing indicator light flashing at the same time direction, the direction indicator light flashes slowly when near the fast frequency, when the voice sounded very strong in the gradual reduction of the antenna (step cycle). Full recovery of the day line, the indicator light flashes at the same time the voice sounded the same as with the above, suspicious objects on the 10+40 cm in your range.

5, Asked: "ghost detector" you need to replace the battery?

Answer: No.

"Ghost detector" using energy-saving design, the amount is very small, most people use, a battery of up to 1-2 years.

Using a remote control car batteries,