

75 APPLICATIONS

FOR YOUR PHILIPS TAPE RECORDER

Business and Industry, Shops

Dictation of letters
Dictations for part-time typists
Meetings, conferences
Surveys, reports
Discussions
Instructions to employees
Important telephone conversations
Sound publicity
Commentary to slides & filmstrips
Commentary to flannel boards
Commentary to silent or foreign language training films
Stock-exchange quotations
Telephonic orders to stockbrokers
Music in worktime
Relay of information
Background music
Announcements to public
Repetition of slogans
Explanations to demonstrations
Recorded non-stop music

Music

General musical education
Hearing & rhythm training
Demonstrating errors & defects
Recognizing instruments
Judging progress
Judging own presentation
Objective comparison
Self-criticism
Singing lessons
Instrumental lessons
Ensemble playing
Recitals
Choirs
Orchestras
Recorded accompaniments
Choral societies

At home

Family sound album
Children's voices
Spoken letters to relatives
International tape correspondence
Weddings, reunions, jubilees
Parties & celebrations
Music library
Non-stop popular music
Uninterrupted concerts
Delayed radio programmes
Recording of broadcasts during absence
Talking books for old people & invalids
Sound-tracks for amateur films

Science, Medicine, Exploration



Laryngology
Psycho-analysis
Hypnopaedic use
Chest & Heart sounds
Deaf-and-Dumb training
Medical training
Medical congresses
Recording operation commentary
Correcting speech disorders
Recording native dialects
Local music & sounds
Linguistic studies
Verbal reports of expeditions
Bird, animal & insect sounds

Miscellaneous

Background music on the stage
Background noises for plays
Rehearsals and performances
Sound effects
Spoken books and courses for the blind
Sermons for ill and aged people
Reporting
Interviews
Music for rhythmical exercises
Folk-dancing
Historical speeches
Tape recording clubs



PHILIPS TAPE RECORDER EL 3542



Mains voltage

- A. Mains lead (in bottom compartment)
- B. Voltage adapter
- C. Speed buttons, also used to switch the recorder on
- D. Switching-off button, to switch the recorder off completely

Sockets

- E. For microphone or telephone coil
- F. For recordings from radio set, record player or second tape recorder
- G. For additional loudspeaker
- H. For playback via radio set or hi-fi installation
- I. For monitoring by means of headphones during recordings
- J. STEREO output (2nd playback head)

Recording

- K. Recording button with the interlocking button behind it
- L. Volume control for microphone
- M. Volume control for recordings made from radio set, record player or 2nd tape recorder
- N. Recording level indicator (magic eye)
- O. Track selector
- P. Super-impose lever

Playback

- Q. Playback button
- R. Volume control
- S. Tone control

Tape

- T. Button for short interruptions with the unlocking button behind it
- U. Rewind button
- V. Fast forward wind button for locating a given passage on the tape
- W. Stop-button
Depressed halfway: for stopping the tape and making the recording, playback or fast forward wind buttons spring back to inoperative position
Depressed completely: for using the tape recorder as an amplifier for the microphone or record player
- X. Counting mechanism for locating a given passage on the tape

