


REMOTE CONTROL



1. POWER/SOURCE
2. MUTE
3. NUMBER BUTTONS
4. MENU / *
5. AUDIO / #
6. LOUD / EQ
7. UP (Tune up)
8. LEFT (Seek Down)
9. ENTER / BAND
10. PROGRAM

13. PREVIOUS
14. SLOW / END CALL
15. TITLE / PBN
16. ZOOM / CALL
17. SUBTITLE / PBP
18. OPEN / CLOSE / P.ANGLE
19. SETUP
20. VOLUME+
21. VOLUME-
22. DISPLAY

25. SYSTEM/NAVI
26. F.FWD
27. RIGHT(Seek up)
28. STOP
29. D.ANGLE
30. PLAY / PAUSE
31. NEXT
32. A-B / PHONE PAIR
33. REPEAT / PHONE
34. PAL / NTSC / AP